



PRESS SCREEN ASSEMBLY

1. Unscrew the Lid Stem from the Metal Base.
2. Turn the lid upside down so the screw at the base of the Lid Stem is facing up.
3. Take the Spring Screen (A.) and turn it upside down. Slide it onto the screw so the springs face away from you.
4. Take the Plastic Screen (B.) and place it on the back of the Spring Screen by sliding it onto the screw.
5. Take the Mesh Screen (C.) and turn it upside down. Slide the Mesh Screen onto the screw over the Plastic Screen. The lip of the mesh screen should overlap the other 2 screens.
6. Take the Metal Base and turn it upside down so it threads with the screw. Tighten the base so the screens stay in place.

(Please note the Lid Stem & Metal Base are not included with this set.)

SERVICE IDEAS, INC.

2354 VENTURA DRIVE ~ WOODBURY, MN 55125

800-328-4493 ~ WWW.SERVICEIDEAS.COM

11-9G-20